

Säkerhetskylt för chaufförer och
Dahl operatör av lastmaskin

DRIVER

Safety
First

(UN)LOADING SAFETY RULES




(UN)LOAD ONLY IN
DESIGNATED AREA



WEAR APPROPRIATE PPE



SPEAK TO A DAHL CONTACT
BEFORE STARTING ANY
OPERATION ON SITE



ENSURE THAT THE TRUCK IS
IMMOBILIZED BEFORE
(UN)LOADING
OPERATIONS BEGIN



REMOVE SECURING
DEVICES ONLY IF THE
LOAD IS STABLE



GET OUT OF THE
WAY AND LET A
LOAD FALL



RESPECT PEDESTRIAN
RULES WHEN ON SITE



STAY IN THE DESIGNATED
SAFE AREA UNTIL YOUR DAHL
CONTACT AUTHORIZES YOU
TO LEAVE IT



STOP AND REPORT ANY
UNSAFE SITUATION TO YOUR
DAHL CONTACT

Secure load according to TSFS 2017:25
and 2014/47/EU

DAHL

DAHL OPERATOR

(UN)LOADING SAFETY RULES



PERFORM THE (UN)LOADING OPERATIONS ONLY IF AUTHORIZED



WEAR APPROPRIATE PPE



TAKE RESPONSIBILITY FOR MAKING SURE SAFETY RULES ARE APPLIED



ENSURE THAT THE LOAD REMAINS STABLE AT ALL TIMES



ENSURE THE DANGER ZONE AROUND THE LOAD IS RESPECTED DURING (UN)LOADING



ENSURE THE AREA IS FREE FROM PEDESTRIAN AT ALL TIMES DURING (UN)LOADING



USE APPROPRIATE EQUIPMENT TO HANDLE THE LOAD



(UN)LOAD IN AN ORDER THAT ENSURES THE LOAD ON THE TRUCK IS BALANCED



STOP AND REPORT ANY UNSAFE SITUATION